



*Standard Philips RC5 protocol

Functions

1


2

3

Function	RC5 code
Power	50
Volume up	51
Volume down	52
Move left	55
Move right	54
Mute	53
Function 1	56
Function 2	57
Function 3	58
Function 4	61
Select	48
Device code	16

Installation

- Remove the battery cover
- Place a CR2032 battery with the '+' as in picture
- Put back the battery cover





contact with clip A

Warranty

The work carries warranty out for all provable material and production defects for the duration of 12 months starting from sales. All damage, which is caused by wrong or inappropriate operation, is excluded from the warranty.

For technical matters or questions about the functionality of this product please contact:

support@hypex.nl www.hypex.nl

